

# EASY WIRING, DIY BY YOURSELF

When power line input through the L and N, please screw down to penetrate the insulating

